

**APPENDIX L - POST THRESHOLD INTERVALS FOR STRUCTURES AND ZONAL TASKS****A. GENERAL**

This appendix was created to provide operators with the intervals for selected zonal and structures tasks that must be used upon the airplane reaching the supplemental fatigue inspection threshold. These tasks have intervals that have been escalated beyond what was originally considered for satisfying the damage tolerance requirements of FAR 25.571. The items listed below must use the post-threshold interval upon reaching the defined threshold as stated in the Airworthiness Limitations and Certification Maintenance Requirements Document D622W001-9 (MPD Section 9), in order to ensure the maintenance program complies with the damage tolerance requirements for the 777 aircraft.

**POST THRESHOLD INTERVALS**

<b>MRB / MPD Item Number</b>	<b>Task Description</b>	<b>Inspect Level</b>	<b>Pre Threshold Interval</b>	<b>Post Threshold Interval</b>
52-501-00	Forward Large Cargo Door Main Latch Cam Assemblies at the lower edge of the door.	EXT - GVI	1000 FC 375 DY	700 FC 175 DY
52-502-00	Forward Large Cargo Door Hinges and Hinge Pins including attaching Structure.	EXT - DET	6000 FC 1125 DY	4000 FC 750 DYS
52-510-00	Aft Large Cargo Door Hinges and Hinge Pins including attaching Structure.	EXT - DET	6000 FC 1125 DY	4000 FC 750 DYS
52-802-00	Forward Large Cargo Door	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-806-00	Aft Small Cargo Door	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-810-00	Aft Large Cargo Door	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-814-00	Bulk Cargo Door	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-816-01	Left No. 1 Passenger Entry Door - Section 41	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-820-01	Left No. 2 Passenger Entry Door - Section 43, Sta 764.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-824-01	Left No 3 Overwing Door - Section 44, STA 1180.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-826-01	Left No. 3 Passenger Entry Door - Section 46	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
52-827-01	Left No. 4 Passenger Entry Door - Section 46	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-830-01	Left No. 4 Passenger Entry Door - Section 47	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-831-01	Left No. 5 Passenger Entry Door - Section 47	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-834-02	Right No. 1 Passenger Entry Door - Section 41	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-840-02	Right No. 2 Passenger Entry Door - Section 43	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-844-02	Right No. 3 Overwing Door - Section 44	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-848-02	Right No. 3 Passenger Entry Door - Section 46	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-849-02	Right No. 4 Passenger Entry Door - Section 46	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-852-02	Right No. 4 Passenger Entry Door - Section 47	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
52-853-02	Right No. 5 Passenger Entry Door - Section 47	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-509-01	Forward Cargo Compartment - Large Cargo Door - Cutout Structure including skin within 20 inch periphery of cutout	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-518-00	Main Landing Gear Wheel Well, Left side of body Splice, Rear Spar	EXT - DET	6000 FC 1125 DY	4000 FC 750 DYS
53-519-00	Main Landing Gear Wheel Well, Right side of Body Splice, Rear Spar	EXT - DET	6000 FC 1125 DY	4000 FC 750 DYS
53-522-01	Aft Cargo Compartment - Aft Small Cargo Door - Cutout Structure including Skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-523-01	Aft Cargo Compartment - AFT Large Cargo Door - Cutout Structure including skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
53-529-01	Area Below Aft Cargo Compartment - Aft Small Cargo Door - Cutout Structure including skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-530-01	Area Below Aft Cargo Compartment - Aft Large Cargo Door - Cutout Structure including Skin within 20 inch periphery of cutout	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-532-00	Area Below Aft Cargo Compartment - Aft Small Cargo Door - Cutout Structure for door corners 10 inch radius around sill / edge frame interfaces. Aft Small Cargo Door - Cutout Stop/Roller/Hook Fittings and Backup Structure for 6 inch radius around roller/sill interfaces.	IN-DET	12000FC 2250 DY	8000FC 1500DY
53-532-01	Area Below Aft Cargo Compartment - Aft Small Cargo Door - Cutout Structure for door corners 10 inch radius around sill / edge frame interfaces. Aft Small Cargo Door - Cutout Stop/Roller/Hook Fittings and Backup Structure for 6 inch radius around roller/sill interfaces.	IN-DET	12000FC 2250 DY	8000FC 1500DY
53-533-00	Area Below Aft Cargo Compartment - Aft Large Cargo Door - Cutout Structure for Door Corners 10 inch radius around sill / edge frame interfaces. Aft Large Cargo Door - Cutout Latches and Backup Structure for 6 inch radius around latch / sill interfaces.	IN-DET	12000FC 2250 DY	8000FC 1500DY
53-533-01	Area Below Aft Cargo Compartment - Aft Large Cargo Door - Cutout Structure for Door Corners 10 inch radius around sill / edge frame interfaces. Aft Large Cargo Door - Cutout Latches and Backup Structure for 6 inch radius around latch / sill interfaces.	IN-DET	12000FC 2250 DY	8000FC 1500DY
53-535-00	Bulk Cargo Compartment - Bulk Cargo Door - Cutout Stop Fittings	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-543-00	Overwing Wing-To-Body Fairings, Left Side of Body Splice, Upper Surface	IN - GVI	16000 FC 3000 DY	8000 FC 1500 D
53-544-00	Overwing Wing-To-Body Fairings, Right Side of Body Splice, Upper Surface	IN - GVI	16000 FC 3000 DY	8000 FC 1500 DY
53-551-00	Passenger Compartment - Left - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-551-01	Supernumerary Cabin - Left - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-552-00	Passenger Compartment - Right - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-552-01	Supernumerary Cabin - Right - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
53-553-00	Passenger Compartment - Left - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-554-00	Passenger Compartment - Right - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-562-00	Passenger Compartment - Left - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-563-00	Passenger Compartment - Right - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-564-00	Passenger Compartment - Left - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-565-00	Passenger Compartment - Right - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-582-00	Passenger Compartment - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-583-00	Passenger Compartment - Entry Door - Cutout Stop Fittings.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-584-00	Passenger Compartment - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-585-00	Passenger Compartment - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout. Aft Small Cargo Door - Cutout Structure including skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-586-00	Passenger Compartment - Entry Door - Cutout Structure including edge frames and skin within 20 inch periphery of cutout. Aft Large Cargo Door - Cutout Structure including skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-587-00	Main Deck Cargo Door - Cutout Latches, Roller and Backup Structure, except backup structure.	EXT - GVI	1000 FC 375 DY	650 FC 240 DY
53-595-00	Area above Passenger Compartment Ceiling - Circumferential skin/stringer splice body station 1832.	EX-GVI	12000FC 2250 DY	8000FC 1500DY
53-599-00	Passenger Compartment - Entry door - Cutout stop fitting.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
53-601-00	Passenger Compartment - Entry door - Cutout stop fitting.	EXT - GVI	2000 FC 480 DY	800 FC 480 DY
53-602-00	Passenger Compartment - Entry door - Cutout structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-603-00	Passenger Compartment - Entry Door - Cutout structure including edge frames and skin within 20 inch periphery of cutout.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-611-00	Area above Wing Center Section - Area of inspection includes structure beneath galley only.	INT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-614-00	PASSENGER COMPARTMENT - No.3 Overwing Door - Cutout Structure including skin within 20 inch periphery of cutout (Door closed),edge frames and sills visible when door is open.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DYS
53-800-00	Lower Half of Fuselage.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-804-00	Nose Radome with Radome (111AL) in Open Position.	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-806-00	Area Forward of the Nose Landing Gear Wheel Well.	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-818-00	Perform an Internal Zonal Inspection (GV) of the Forward Cargo Compartment - STA 409 to 998 with ceiling and sidewall liners removed.	INT - ZON	12000FC 2250 DY	8000FC 1500DY
53-830-00	Perform an Internal Zonal Inspection (GV) of the Left / Right Environmental Control Systems Bay with the blankets removed.	INT - ZON	12000FC 2250 DY	8000FC 1500DY
53-838-00	Left Main Landing Gear Wheel Well - STA 1245 to 1434 with Landing Gear Doors in Open position	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-842-00	Right Main Landing Gear Wheel Well - STA 1245 to 1434 with Main Landing Gear Doors in open position	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-888-00	Perform an Internal Zonal Inspection (GV) of the Left Underwing Wing-to-Body Fairing area - STA 1014 to 1241.	INT - ZON	8000FC 1500 DY	8000FC 1500DY
53-890-00	Perform an Internal Zonal Inspection (GV) of the Right Underwing Wing-to-Body Fairing area - STA 1014 to 1241.	INT - ZON	8000FC 1500 DY	8000FC 1500DY
53-896-00	Perform an External Zonal Inspection (GV) of the Upper Fuselage Right and Left - Section 41 through 47 - BS 246 to 2150, Passenger Floor Line (waterline 200) to Top of Fuselage (Fuselage Centerline)	EXT - ZON	12000FC 2250 DY	8000FC 1500DY



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
53-898-00	Left and Right Upper Fuselage (including the top portion of the Radome) - Flight Compartment - STA 92.5 to STA 246, Flight Compartment Floor Line (Waterline 207.5) to Top of Fuselage (Fuselage Centerline).	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
53-924-00	Perform an External Zonal Inspection (GV) of the Left and Right Fuselage aft of the Pressure Dome (Pressure Bulkhead STA 2150) and the APU Compartment - Body Section 48 - STA 2150 to STA 2570 with APU Doors Closed. Top of Fuselage (B/L 0) to Bottom of Fuselage (B/L 0)	EXT - ZON	12000FC 2250 DY	8000FC 1500DY
54-802-01	Internal Zonal (GV) Inspection of the Forward Strut Fairing - Left Nacelle Strut.	INT - ZON	4000 FC 1500 DY	4000 FC 750 DY
54-812-02	Internal Zonal (GV) Inspection of the Forward Strut Fairing - Right Nacelle Strut.	INT - ZON	4000 FC 1500 DY	4000 FC 750 DY
54-822-01	Forward Strut Fairing - Left Nacelle Strut.	INT - ZON	6000 FC 1500 DY	4000 FC 750 DYS
54-824-01	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
54-832-02	Forward Strut Fairing - Right Nacelle Strut.	INT - ZON	6000 FC 1500 DY	4000 FC 750 DYS
54-834-02	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
54-842-01	Forward Strut Fairing - Left Nacelle Strut.	INT - ZON	6000 FC 1500 DY	4000 FC 750 DYS
54-844-01	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
54-852-02	Forward Strut Fairing - Right Nacelle Strut.	INT - ZON	6000 FC 1500 DY	4000 FC 750 DYS
54-854-02	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
55-501-00	Horizontal Stabilizer Center Section - UPPER EXTERNAL SPLICE PLATE. LOWER EXTERNAL SPLICE PLATE. FRONT SPAR UPPER SPLICE FITTING. FRONT SPAR LOWER SPLICE FITTING. FRONT SPAR WEB SPLICE PLATE. REAR SPAR EXTERNAL SPLICE FITTINGS.	EXT - DET	6000 FC 1125 DY	4000 FC 750 DYS
55-502-00	Horizontal Stabilizer Center Section - JACKSCREW FITTING.	EX-DET	12000FC 2250 DY	8000FC 1500DY



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
55-509-00	Vertical Stabilizer - Auxiliary Spar to Front Spar - ROOT ATTACHMENT FITTINGS, FRONT SPAR, LEFT AND RIGHT, lug face only.	EX-DET	12000FC 2250 DY	8000FC 1500DY
55-511-00	Vertical Stabilizer - Front Spar to Rear Spar - ROOT ATTACHMENT FITTINGS, REAR SPAR, LEFT AND RIGHT, lug faces only. ROOT ATTACHMENT FITTINGS, STRINGER 3, LEFT AND RIGHT, lug faces only. ROOT ATTACHMENT FITTINGS, STRINGER 6, LEFT AND RIGHT, lug faces only.	EX-DET	12000FC 2250 DY	8000FC 1500DY
55-515-00	Vertical Stabilizer - Rear Spar to Trailing Edge - TRAILING EDGE HINGE RIBS 2, 3, 4 AND 5 at Fin Stations 207.0, 232.0, 257.0 and 282.0. ACTUATOR FITTINGS.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-515-01	Vertical Stabilizer - Rear Spar to Trailing Edge - TRAILING EDGE HINGE RIBS 2, 3, 4 AND 5 at Fin Stations 207.0, 232.0, 257.0 and 282.0. ACTUATOR FITTINGS.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-517-00	Vertical Stabilizer - Rear Spar to Trailing Edge - RUDDER FRONT SPAR forward face only (Rudder Station 199.21-274.12).	IN-GVI	12000FC 2250 DY	8000FC 1500DY
55-517-01	Vertical Stabilizer - Rear Spar to Trailing Edge - RUDDER FRONT SPAR forward face only (Rudder Station 199.21-274.12).	IN-GVI	12000FC 2250 DY	8000FC 1500DY
55-518-00	Vertical Stabilizer - Rear Spar to Trailing Edge - HINGE FITTINGS 2, 3, 4 AND 5 at Fin Stations 207.0, 232.0, 257.0 and 282.0. ACTUATOR FITTINGS. TAB PUSH-RODS.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-518-01	Vertical Stabilizer - Rear Spar to Trailing Edge - HINGE FITTINGS 2, 3, 4 AND 5 at Fin Stations 207.0, 232.0, 257.0 and 282.0. ACTUATOR FITTINGS. TAB PUSH-RODS.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-521-00	Rudder Tab - SPAR forward face only.	IN-GVI	12000FC 2250 DY	8000FC 1500DY
55-522-00	Rudder Tab - TAB PUSH-RODS. TAB HINGE FITTINGS. TAB PUSH-ROD FITTINGS.	IN-GVI	12000FC 2250 DY	8000FC 1500DY
55-527-01	Left Horizontal Stabilizer Center Section - PIVOT FITTING, STRAPS, AND PIN.	EX-DET	12000FC 2250 DY	8000FC 1500DY
55-534-01	Left Horizontal Stabilizer - Rear Spar to Trailing Edge - TRAILING EDGE HINGE RIBS 8, 9, AND 10 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including kick link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-534-03	Left Horizontal Stabilizer - Rear Spar to Trailing Edge - TRAILING EDGE HINGE RIBS 8, 9, AND 10 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including kick link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-535-01	Left Horizontal Stabilizer - Rear Spar to Trailing Edge - SPAR (Elevator Station 157.29-207.29). HINGE FITTINGS 3, 4, AND 5 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including reaction link.	IN-DET	12000FC 2250 DY	8000FC 1500DY



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
55-535-03	Left Horizontal Stabilizer - Rear Spar to Trailing Edge - SPAR (Elevator Station 157.29-207.29). HINGE FITTINGS 3, 4, AND 5 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including reaction link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-538-02	Right Horizontal Stabilizer Center Section - PIVOT FITTING, STRAPS, AND PIN.	EX-DET	12000FC 2250 DY	8000FC 1500DY
55-545-02	Right Horizontal Stabilizer - Rear Spar to Trailing Edge - TRAILING EDGE HINGE RIBS 8, 9, AND 10 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including kick link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-545-04	Right Horizontal Stabilizer - Rear Spar to Trailing Edge - TRAILING EDGE HINGE RIBS 8, 9, AND 10 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including kick link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-546-02	Right Horizontal Stabilizer - Rear Spar to Trailing Edge - SPAR (Elevator Station 157.29-207.29). HINGE FITTINGS 3, 4, AND 5 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including reaction link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-546-04	Right Horizontal Stabilizer - Rear Spar to Trailing Edge - SPAR (Elevator Station 157.29-207.29). HINGE FITTINGS 3, 4, AND 5 at Stabilizer Stations 244.4, 269.4, and 294.4 at rear spar. ACTUATOR FITTINGS including reaction link.	IN-DET	12000FC 2250 DY	8000FC 1500DY
55-828-01	Perform an External Zonal Inspection of the Left Horizontal Stabilizer Center Section.	EXT - ZON	12000FC 2250 DY	8000FC 1500DY
55-848-02	Perform an External Zonal Inspection of the Right Horizontal Stabilizer Center Section.	EXT - ZON	12000FC 2250 DY	8000FC 1500DY
57-501-00	Wing Center Section - REAR SPAR, lower chord horizontal and vertical legs only, from left side of body to right side of body LOWER PANEL, access hole 139AZ only.	IN-DET	12000FC 2250 DY	8000FC 1500DY
57-502-01	Slat Number 7 - INBOARD SLAT, TRAILING EDGE WEDGE.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DY
57-504-01	SLATS NUMBER 1 THROUGH 6, OUTBOARD SLATS, TRAILING EDGE WEDGES	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DY
57-505-01	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - LOWER PANEL, at rear spar. LOWER PANEL, at access holes.	EX-DET	8000FC 2250 DY	8000FC 1500DY
57-507-01	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - LOWER PANEL at access holes, rear spar and rib 45 to skin.	EX-GVI	8000FC 2250 DY	8000FC 1500DY



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
57-515-01	Left Wing Inboard Main Flap - INBOARD MAIN FLAP REAR SPAR, at rib interface only.	EX-DET	12000FC 2250 DY	8000FC 1500DY
57-519-01	Left Wing Flaperon - FLAPERON INBOARD ACTUATOR FITTING. FLAPERON OUTBOARD ACTUATOR FITTING.	IN-GVI	12000FC 2250 DY	8000FC 1500DY
57-520-01	Left Wing Flaperon - FLAPERON INBOARD and OUTBOARD ACTUATOR FITTING interfaces.	IN-DET	12000FC 2250 DY	8000FC 1500DY
57-533-01	Outboard Flaperon Support Fairing - Left Wing - FLAPERON OUTBOARD FIXED SUPPORT. FLAPERON OUTBOARD BEARING BLOCK. FLAPERON OUTBOARD ACTUATOR FITTING.	IN-GVI	12000FC 2250 DY	8000FC 1500DY
57-535-02	Slat Number 8 - INBOARD SLAT, TRAILING EDGE WEDGE.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DY
57-538-02	Slats Number 9 Through 14 - OUTBOARD SLATS, TRAILING EDGE WEDGES.	EXT - GVI	6000 FC 1125 DY	4000 FC 750 DY
57-540-02	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - LOWER PANEL, at rear spar. LOWER PANEL, at access holes.	EX-DET	8000FC 2250 DY	8000FC 1500DY
57-542-02	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - LOWER PANEL, at access holes, rear spar and rib 45 to skin.	EX-GVI	8000FC 2250 DY	8000FC 1500DY
57-550-02	Right Wing Inboard Main Flap. Inboard Main Flap Rear Spar, at rib interface only.	EX-DET	12000FC 2250 DY	8000FC 1500DY
57-554-02	Right Wing Flaperon - FLAPERON INBOARD ACTUATOR FITTING. FLAPERON OUTBOARD ACTUATOR FITTING.	IN-GVI	12000FC 2250 DY	8000FC 1500DY
57-555-02	Right Wing Flaperon - FLAPERON INBOARD and OUTBOARD ACTUATOR FITTING interfaces.	IN-DET	12000FC 2250 DY	8000FC 1500DY
57-563-02	Outboard Flaperon Support Fairing - Right Wing - FLAPERON OUTBOARD FIXED SUPPORT. FLAPERON OUTBOARD BEARING BLOCK FLAPERON OUTBOARD ACTUATOR FITTING.	IN-GVI	12000FC 2250 DY	8000FC 1500DY
57-804-01	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing.	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-808-01	Slat No. 7.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-816-01	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

MRB / MPD Item Number	Task Description	Inspect Level	Pre Threshold Interval	Post Threshold Interval
57-817-01	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing.	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-818-01	Outboard Leading Edge Slats Number 1 through 6.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-840-01	Perform an External Zonal Inspection (GV) of the Left Wing Inspar area (fuel tanks) from Rib 17, WS 626, to Wing Tip - Upper and Lower Wing surface.	EXT - ZON	12000FC 2250 DY	8000FC 1500DY
57-854-01	Rear Spar to Landing Gear Support Beam - Left Wing.	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-896-02	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-900-02	Slat No. 8.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-908-02	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-909-02	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing	INT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-910-02	Outboard Leading Edge Slats Number 9 through 14.	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS
57-932-02	Perform an External Zonal Inspection (GV) of the Right Wing Inspar Area (Fuel Tanks) from Rib 17, WS 626, to Wing Tip - Upper and Lower Wing Surface.	EXT -ZON	12000FC 2250 DY	8000FC 1500DY
57-946-02	Rear Spar to Landing Gear Support Beam - Right Wing	EXT - ZON	6000 FC 1125 DY	4000 FC 750 DYS